

USE THIS CHART TO DETERMINE THE S.W.L FOR THE CRANE WHEN:

1. LIFTING STERN OR BOW
2. INFLAT CALM WATER
3. USING MAIN BLOCK - 6 FALLS

ON NO ACCOUNT DURING ANY LIFTING OPERATION SHOULD THE FREEBOARD AT ANY POINT ON THE BARGE BE LESS THAN 250mm

LINKBELT CRANE TC218
MOUNTED ON BARGE
"TMS MAVERICK"

S.W.L. MAIN BLOCK
USING 6 FALLS
WHEN LIFTING OVER
THE STERN OR BOW
OF THE BARGE

FLY JIB MAXIMUM
LOAD AT ANY
RADIUS 4.25
TONNES

IF IN DOUBT
ASK

DATA PREPARED BY
BRIAN KNIGHT
C.ENF.,M.I.MAR.E.

